

INSTALLATION INSTRUCTIONS

Dead pedal Porsche 911/964/993

PLEASE READ BEFORE INSTALLATION:

Silverlake Projects products are intended for racing or off-road use, and should be installed by a qualified automotive technician.

The use of Silverlake Projects products is the sole responsibility of the customer. Silverlake Projects accepts no responsibility for warranty voids or damage resulting from the installation or use of its parts and products. Giving significant variability in the location of electrical wiring and fluid lines, it is the user responsibility to carefully inspect any area prior to drilling.

INSTRUCTIONS:

1. Place the dead pedal in the desired location
2. Make sure the tires are straight or turned towards the passenger side to avoid puncture
3. Determine and mark holes for mounting.
4. Center punch and drill holes in the inner fender with a XX XX drill (XX XX mm) drill bit
5. Install the dead pedal with the supplied screws
6. You can alternatively use your own self-drilling screws

