

---

## 2016-2019 Porsche 718 Boxster and Cayman Front Radiator Grill Installation Procedure



Note: it is best to protect your paint with painter's tape during the installation procedure.



## Procedure

---

1. Protect edges where the grill will be carefully inserted with painter's tape. Insert the grill through the top opening in the stock slated bumper strakes.



2. Cable ties are preinstalled for ease of installation. Once the grill is inserted, you will be able to rotate the side in your hand into the cavity of the radiator intake. Connect all cable ties, but do not tighten. Once all are connected, rotate the receiver end of the cable tie towards the grill. Once done for all cable ties, tighten by holding the receiver end close to the grill and pull.



3. Clip off the ends of the cable ties. Complete!

