

Part No's. ZPR44213

Page 1 of 2 Iss 1 Oct 2013

Porsche 981 Cayman Manual & PDK Without Parking Sensors Stainless Steel Sports Side Grille Kit

Kit Contents: -

- 1. off LH Upper Grille
- 1. off LH Centre Grille
- 1. off LH Lower Grille
- 1. off RH Upper Grille
- 1. off RH Centre Grille
- 1. off RH Lower Grille
- 8. off No6 x ³/₄" Screws



Upper Side Mesh Grille Fitting Instructions (Please fit the grilles in this order)

- 1. Fit masking tape around all of the apertures to protect the paintwork while fitting as shown in fig 1.
- 2. Locate Grille Level with aperture.
- 3. Insert the screw into the diamond through mesh and tighten down as shown in fig 2 then repeat to the other screw (do not over tighten).
- 4. Repeat steps1, 2 and 3 to the opposite grille.
- 5. Remove the tape and the grilles are now complete.





Fig 2



Lower Side Mesh Grille Fitting Instructions <u>THANK YOU FOR CHOOSING A ZUNSPORT PRODUCT.</u>





Part No's. ZPR44213

Page 2 of 2 Iss 1 Oct 2013

- 1. Fit masking tape around the apertures to protect the paintwork while fitting.
- 2. Firstly locate the outer part of the grille into the aperture as shown in fig 1.
- 3. Locate the inner bracket making sure it clips behind the aperture fig 2. (You can use a long thin screw driver to make sure it has clipped in position or by putting your hand through the centre aperture).
- 4. Once grille is in correct position insert the screw into the diamond through mesh and tighten down (do not over tighten).
- 5. Repeat steps1, 2 and 3 to the opposite grille.
- 6. The grilles are now complete.





Centre Side Mesh Grille Fitting Instructions

- 1. Fit masking tape around the apertures to protect the paintwork while fitting.
- 2. Firstly locate the outer part of the grille into the aperture as shown in fig 1 & 2.
- 3. Locate the inner bracket making sure it clips behind the aperture. (You can use a long thin screw driver to make sure it has clipped in position).
- 4. Once grille is in correct position insert the screw into the diamond through mesh and tighten down as shown in fig 3 (do not over tighten).
- 5. Repeat steps1, 2 and 3 to the opposite grille.
- 6. The grilles are now complete.



THANK YOU FOR CHOOSING A ZUNSPORT PRODUCT.

