


Gear knob installation instruction

1. Remove the original gear knob.
2. Remove decorative screw from gear knob



3. Put decorative screw to lever.
4. Put gear knob on the lever pushing it down right to the end.
5. Tighten the lateral screws, pushing constantly on the gear knob.



6. Screw back decorative screw.
7. If Gear knob is well fixed, You are done.